



REV. 02 - 19/09/2018

HOW TO CHOOSE THE CORRECT RELEASE VALUE WHEN PURCHASING "TROFEO" AND "TROFEO PLUS" BINDINGS

Check your bodyweight (including apparel and gear) and adapt it with the "SKIER'S ABILITY AND PHYSICAL CONDITION CORRECTION FACTORS".

Take the resulting weight and insert it into the "SKIERS' WEIGHT TABLE" to get out the correct binding release value for the user.

SKIER'S ABILITY CORRECTION FACTORS

1	SKIER'S WEIGHT - 10 KG
2	SKIER'S WEIGHT
3	SKIER'S WEIGHT +10 KG

SKIER'S PHYSICAL CONDITION CORRECTION FACTORS

1	SKIER'S WEIGHT VALUE -10 KG
2	SKIER'S WEIGHT VALUE
3	SKIER'S WEIGHT VALUE +10 KG

SKIER'S ABILITY DEFINITION:

1 --> BEGINNER
2 --> REGULAR
3 --> ADVANCED/EXPERT

SKIER'S PHYSICAL CONDITION DEFINITION:

1 --> WEAK
2 --> REGULAR
3 --> TRAINED

SKIER'S WEIGHT (KG)

< 50
50 - 70
70 - 90
> 90

HEEL RELEASE VALUE

4
6
8
10

WARNING! DANGER!

- The ATK binding models "TROFEO" and "TROFEO PLUS" DO NOT COMPLY WITH ANY DIN/ISO SAFETY STANDARD (in particular these do not comply with DIN/ISO 11088, nor DIN/ISO 13992).
- "TROFEO" and "TROFEO PLUS" are anyway provided with pre-set release systems for the LATERAL (Mz) and VERTICAL (My) release: choosing the most correct pre-set system value for the skier specifics may reduce the risk of injury for the limbs under the femur.
- The stated pre-set values for Mz and My release must be considered as indicative: the effective release value could significantly differ from the stated value.
 - In case you desire to switch the pre-set "U" spring with a different value one, you must get in contact with an authorized dealer: a self-made operation and/or made by non-formed technicians and/or without the help of the needed release value checking machineries, it's strongly not recommended and could lead to a cancellation of the warranty period.
- Refer to the Product User's Guide for the whole information regarding the use of these products.